R438B/29367 FISH TAPE SWIVEL TIP



AWARNING

Wear eye protection when using or servicing this tool. Failure to wear eye protection can result in serious eye injury from flying debris or from the end of the fish tape.



AWARNING

Hot surfaces can cause burns. Do not touch the tape. the end of the torch, or any other heated surfaces. Failure to observe this warning can result in severe injury.

ACAUTION

An improperly treated tape can break. Heat the tape completely and allow it to air cool. Do not quench.


Failure to observe this precaution can result in injury or property damage.

Preparation

- Tape without a ball tip: Cut off the loop at the end of the tape.
- Tape with a ball tip: Unscrew the male half of the ball tip from the female half. Slide the female half away from the crimped end of the tape. Cut off the crimp. Remove the female half from the tape.

999 2775.6	© 2001 Greenlee Textron	Printed in the U.S.A.	IM 1339 REV 1 9/01

R438B/29367 FISH TAPE SWIVEL TIP



Wear eve protection when using or servicing this tool. Failure to wear eye protection can result in serious eye injury from flying debris or from the end of the fish tape.



AWARNING

Hot surfaces can cause burns. Do not touch the tape. the end of the torch, or any other heated surfaces. Failure to observe this warning can result in severe iniurv

ACAUTION


An improperly treated tape can break. Heat the tape completely and allow it to air cool. Do not quench.

Failure to observe this precaution can result in injury or property damage.

Preparation

- · Tape without a ball tip: Cut off the loop at the end of the tape.
- Tape with a ball tip: Unscrew the male half of the ball tip from the female half. Slide the female half away from the crimped end of the tape. Cut off the crimp. Remove the female half from the tape.

- 1. Slide the female half of the ball tip, narrow end first, onto the tape. See Figure 1.
- 2. Grip the tape with a pair of insulated pliers. Use a torch to heat the tape until it is a dull red color. See Figure 2.
- Use another pair of insulated pliers to make a 3/16" (4.8 mm) crimp in the 3. tape. See Figure 3. Crimp the tape back to 180°. See Figure 4.
- Allow the tape to air cool completely. The tape should be folded completely 4. back on itself.
- Reheat the tape and allow it to air cool completely. Do not quench. 5.
- Thread the male half of the ball tip into the female half. See Figure 4. Tighten 6. with pliers.
- If the ball tip does not rotate freely, cut off the tip and grind the tape as Note: shown in Figure 5. Form a new crimp as described in Steps 1-6.




GREENLEE

Greenlee Textron / Subsidiary of Textron Inc. 4455 Boeing Drive, Rockford, IL 61109-2988 USA Customer Service (International): 815/397-7070 • Fax: 815/397-1391 Customer Service (North America): 800/435-0786 • Fax: 800/451-2632, 815/397-1865 Canada Fax: 800/524-2853

Replacement

- 1. Slide the female half of the ball tip, narrow end first, onto the tape. See Figure 1.
- Grip the tape with a pair of insulated pliers. Use a torch to heat the tape until it 2. is a dull red color. See Figure 2.
- Use another pair of insulated pliers to make a 3/16" (4.8 mm) crimp in the 3 tape. See Figure 3. Crimp the tape back to 180°. See Figure 4.
- Allow the tape to air cool completely. The tape should be folded completely 4 back on itself.
- Reheat the tape and allow it to air cool completely. Do not quench. 5
- Thread the male half of the ball tip into the female half. See Figure 4. Tighten 6
- with pliers. te: If the ball tip does not rotate freely, cut off the tip and grind the tape as Note: shown in Figure 5. Form a new crimp as described in Steps 1-6.



GREENLEE

Greenlee Textron / Subsidiary of Textron Inc. 4455 Boeing Drive, Rockford, IL 61109-2988 USA Customer Service (International): 815/397-7070 • Fax: 815/397-9247 Customer Service (North America): 800/435-0786 • Fax: 800/451-2632, 815/397-1865 Canada Fax: 800/524-2853

R438B/29367 FISH TAPE SWIVEL TIP



Wear eye protection when using or servicing this tool. Failure to wear eye protection can result in serious eye injury from flying debris or from the end of the fish tape.



AWARNING

Hot surfaces can cause burns. Do not touch the tape, the end of the torch, or any other heated surfaces. Failure to observe this warning can result in severe injury

ACAUTION

An improperly treated tape can break. Heat the tape completely and allow it to air cool. Do not quench.


Failure to observe this precaution can result in injury or property damage.

Preparation

- Tape without a ball tip: Cut off the loop at the end of the tape.
- Tape with a ball tip: Unscrew the male half of the ball tip from the female half. Slide the female half away from the crimped end of the tape. Cut off the crimp. Remove the female half from the tape.

999 2775.6	© 2001 Greenlee Textron	Printed in the U.S.A.	IM 1339 REV 1 9/01
///2//0.0		r mitteu in the 0.5.A.	

R438B/29367 FISH TAPE SWIVEL TIP



Wear eve protection when using or servicing this tool. Failure to wear eve protection can result in serious eve injury from flying debris or from the end of the fish tape.



AWARNING

Hot surfaces can cause burns. Do not touch the tape, the end of the torch, or any other heated surfaces. Failure to observe this warning can result in severe injury

ACAUTION

An improperly treated tape can break. Heat the tape completely and allow it to air cool. Do not quench.


Failure to observe this precaution can result in injury or property damage.

Preparation

- · Tape without a ball tip: Cut off the loop at the end of the tape.
- Tape with a ball tip: Unscrew the male half of the ball tip from the female half. Slide the female half away from the crimped end of the tape. Cut off the crimp. Remove the female half from the tape.

Replacement

- 1. Slide the female half of the ball tip, narrow end first, onto the tape. See Figure 1.
- 2 Grip the tape with a pair of insulated pliers. Use a torch to heat the tape until it is a dull red color. See Figure 2.
- Use another pair of insulated pliers to make a 3/16" (4.8 mm) crimp in the 3. tape. See Figure 3. Crimp the tape back to 180°. See Figure 4.
- Allow the tape to air cool completely. The tape should be folded completely 4. back on itself.
- 5. Reheat the tape and allow it to air cool completely. Do not quench.
- 6. Thread the male half of the ball tip into the female half. See Figure 4. Tighten with pliers.
- Note: If the ball tip does not rotate freely, cut off the tip and grind the tape as shown in Figure 5. Form a new crimp as described in Steps 1-6.




GREENLEE

Greenlee Textron / Subsidiary of Textron Inc. 4455 Boeing Drive, Rockford, IL 61109-2988 USA Customer Service (International): 815/397-7070 • Fax: 815/397-1391 Customer Service (North America): 800/435-0786 • Fax: 800/451-2632, 815/397-1865 Canada Fax: 800/524-2853

Replacement

- 1. Slide the female half of the ball tip, narrow end first, onto the tape. See Figure 1.
- Grip the tape with a pair of insulated pliers. Use a torch to heat the tape until it 2 is a dull red color. See Figure 2.
- Use another pair of insulated pliers to make a 3/16" (4.8 mm) crimp in the tape. See Figure 3. Crimp the tape back to 180°. See Figure 4.
- Allow the tape to air cool completely. The tape should be folded completely 4 back on itself
- Reheat the tape and allow it to air cool completely. Do not quench. 5
- Thread the male half of the ball tip into the female half. See Figure 4. Tighten 6
- with pliers. te: If the ball tip does not rotate freely, cut off the tip and grind the tape as Note: shown in Figure 5. Form a new crimp as described in Steps 1-6.



GREENLEE

Greenlee Textron / Subsidiary of Textron Inc. 4455 Boeing Drive, Rockford, IL 61109-2988 USA Customer Service (International): 815/397-7070 • Fax: 815/397-9247 Customer Service (North America): 800/435-0786 • Fax: 800/451-2632, 815/397-1865 Canada Fax: 800/524-2853